

How to Steam with Your Jiffy® Steamer



As your drycleaner knows, steam is the gentlest, safest, most efficient method to remove wrinkles. Not only is steaming up to five times faster than ironing, it is guaranteed not to scorch even the most delicate materials and fabrics. Our steamers will remove wrinkles from clothing, drapery, tablecloths, virtually any fabric. Jiffy Steamers are great for removing “closet crunch,” and they eliminate most trips to the drycleaner. Use the following information to help guide you to more proficient steaming.



When steaming, touch material lightly with steam head and wrinkles will vanish instantly. The combination of the steam and the steam head is important for a smooth finish. Do not directly touch velvet or silk with the steam head.




Some articles may be steamed better from the underside. This allows the warm, moist steam to penetrate and relax the fibers of the material, thus removing the wrinkles.



Pants may be easily steamed by hanging them by the cuff. You may also use a Jiffy Steamboard to serve as a vertical pressing board to position your garments and set pleats.



Always steam with hose in an upright position so any condensation is free to flow back into the steamer. If steaming in a low position near the floor, frequently straighten hose up and out to keep clear.



Convenient hanger/hook mechanism holds both clothes and steam head securely.



Made in the USA Since 1940 

Jiffy Steamer Company, LLC
4462 Ken-Tenn Highway
Union City, TN 38261
P: 731.885.6690
F: 731.885.6692
jiffysteamer.com
info@jiffysteamer.com